



# Parts Catalog 2015

---

*Parts for the Allis-Chalmers All-Crop Harvester and other AC Machinery. Last update: 2015-9-22*

## **AllCropHarvester.com Parts List**

**To our valued Customers:**

**This catalog lists our current inventory. The first section features parts that are commonly ordered. The second section lists all parts by machine use. If you do not see the part you need, please contact us as we may be able to find it new or used. Availability and pricing subject to change at any time.**

**To order a part contact us via email at [sales@allcropharvester.com](mailto:sales@allcropharvester.com) or call evenings EST 724-383-4290 (6:00PM-10:00 PM).**

**All orders must be pre-paid using cash, check or credit card (via PayPal). Arrangements will be made when you place your order. We may give thirty day terms at our discretion for repeat customers in good standing.**

**Thank-You for your business.**

**KAS LLC**

## AllCropHarvester.com Parts List



### Belts

We have ALL belts for ALL the models. Contact us for pricing.



#### Concave Rubber (504176)

Two used in concave, needs concave bar to hold in place.

Models: 60,60A,72,90

35.00 Ea



#### Concave Bar(513658)

Two used in concave, holds concave rubber in place

Models: 60,60A,72,90

35.00 Ea



#### Draper, Upper (525868)

a.k.a. "Canvas". Rubberized with cleats of rubber coated fiberglass

Field modification required.

Models (60,60A,66)

250.00 Ea



#### Draper, Lower (525872)

a.k.a "Canvas". Rubberized with cleats of rubber coated fiberglass. Field modification required.

Models (60,60A,66)

375.00 Ea



#### Grain Tank Door (523627)

For 25 bushel grain tanks. Note: NOT painted

Models: 66,72 with 25 bushel tanks

49.00 Ea



#### Filler Grain Tank (523641)

For 25 bushel tank. Stainless. Note:NOT painted

Models: 66,72,90

65.00 Ea

## AllCropHarvester.com Parts List



### Clean Grain Elevator Door(520072)

Models: 60,60A,66,72

*49.00 Ea*



### Tailings Door (501161)

Models: 60,60A,66,72

*45.00 Ea*



### Concave Blank

For overlay or replacement. No holes.

Models:60,60A,66,72

*190.00 Ea*



### Shelling Plate(501904)

Use w/ shelling plate lagging

Models:60,60A,66,72

*75.00 Ea*




### Shelling Plate Lagging(507628)

Use with shelling plate. Rivets included.

Models: 60,60A,66,72

*35.00 Ea*



### Tailings Boot(526383)

Special Order as these are handmade – Allow  
4-6 weeks

Models: 60,60A,66,72

*165.00 Ea*

## AllCropHarvester.com Parts List



**Unloading Boot Repair**  
Models:60,60A,66(early)

*70.00 Ea*



**Sheave (520065)**  
The big one on the rear that gets banged up.  
Models: 60,60A,66,72

*145.00 Ea*



**Hub (535485)**  
Used with 520065 Sheave  
Models:60,60A,66,72

*25.00 Ea*



**Wheel Bushing(507344)**  
Two needed per wheel.  
Models: 60,60A,66,early 72

*23.500 Each*



**Seal, Felt (500502)**  
Models:60,60A,66,72

*1.50 Ea*



**Cap (500501)**  
Models:60,60A,66,72

*7.00 Ea*



**Reinforcement, Outer (501603)**  
Models:60,60A,66,72

*15.00 Ea*



**Reinforcement, Inner (504007)**  
Models:60,60A,66,72

*12.00 Ea*

## AllCropHarvester.com Parts List



### Disc (501947)

Models:60,60A,66,72

15.00 Ea



### Elevator Cup Assembly

You assemble. Includes link, cup and rivets

17.00 Ea



### Tailings Paddle Assembly (501167)

Includes link and rivets

Models: 60,60A,66,72


10.00 Ea



### Grain Drag Assembly (507427)

Models: 60,60A,66,72

459.00 Ea



### Ball Bearing (528518) aka 507223

Sealed

Models:60,60A 66,72,90,100SP

15.00 Ea



### Ball Bearing(211227) aka 805050

Models: 60,60A,66,72

20.00 Ea



### Ball Bearing (510313)

Models:60,60A,66,72,90,SP100

20.00 Ea



### Ball Bearing (507223)

Sealed

Models: 60,60A,66,72,90,SP100

20.00 Ea

## AllCropHarvester.com Parts List



### **Roller Bearing(507266)**

Models: 72,90,SP100

*25.00 Ea*



### **Roller Bearing(512164)**

Models: 60,60A,66,72,90,SP100

*10.00 Ea*

# AllCropHarvester.com Parts List



**Decal "60" (517096)**  
 Die-cut  
 Models:60,60A  
 14.00 Ea



**Decal "66" (513686)**  
 Die-cut  
 Models: 66  
 14.00 Ea



**Decal "72" (533191)**  
 Die-cut  
 Models: 72  
 14.00 Ea




**Decal "All-Crop Harvester" (517279)**  
 Die-cut  
 Models: 60,60A,66,72,90  
 47.00 Ea



**Decal Cylinder Settings (517860)**  
 Die-cut  
 Models: 60,60A,66,72  
 16.00 Ea



**Decal Separator Drive (502394)**  
 Die-cut  
 Models: 60,60A,66,72  
 16.00 Ea



**Decal Separator Drive (502394)**  
 Die-cut  
 Models: 60,60A,66,72  
 16.00 Ea



**Slat, Straw Rack(501060)**  
 Models:60,60A,66,72  
 10.00 Ea



**Chain Guide, Straw Rack(507189)**  
 Models:60,60A,66,72  
 10.00 Ea



## AllCropHarvester.com Parts List



### Bearing Block, Straw Rack(501623)

Models: 60,60A,66,72

8.00 Ea



### Bushing(519835)

Models: 60,60A,66

5.00 Ea



### Bushing, Brass (500983)

Models:60,60A,66,72

7.00 Ea



### Bushing, Hanger (527068)

Models: 72,90

17.00 Ea



### Pin (513485)

Models: 66,72

19.00 Ea



### Operators Manual(70828308)

Models:60 (Works well for Model 60 as well)


25.00 Ea



### Operators Manual(70828306)

Models:72

25.00 Ea



### Operators Manual(70828308)

Models:90

25.00 Ea

## AllCropHarvester.com Parts List



### Sickle Section(500760)

Rivets NOT included

Models: 60,60A,66,72,90

3.85 Ea



### Sickle Bar Blank

Models 60,60A,66,72

105.00 Ea



### Filler Plate (503354)

Used, availability varies

Models: 60,60A,66

18.00 Each



### Rub Plate Sickle Bar (535537)

Models : 60,60A,66,72,90

20.00 Ea



### Sickle Guards (515217)

Used, availability varies

Models: 60,60A,66,72,90

8.00 Each



### Bushing, Rubber (533261)

Models: 72

11.95 Ea



### Bushing, Rubber(511238)

Models: 66

14.00 Ea



### Bushing, Rubber(535543) aka K5D-14894

Models: 60,60A

5.00 Ea

## AllCropHarvester.com Parts List

Complete New Parts List		
<b>40 Harvester</b>		
	500332	BAT
	502670	DIVIDER
	503020	AUGER
	503071	GRAIN ELEVATOR RADDLE ASSY
	503188	ROLL
	503298	RADDY ASSY
	503305	BELT
	503306	BELT REEL DRIVE
	504079	PITMAN
	504093	BELT
	504176	RUBBER
	504177	BAR CONCAVE
	504233	GRAIN ELEVATOR BUCKET

## AllCropHarvester.com Parts List

60 Harvester		
	200189	SPRING
	200309	SEAL
	211227	BALL BEARING
	500250	PIN
	500322	BAT
	500323	ARM REEL
	500325	HINGE
	500326	STRAP
	500346	BEARING GRAIN ELEVATOR
	500369	CAP
	500416	BEARING Bagging Attachment
	500501	CAP
	500502	SEAL
	500517	SPACER
	500686	PLATE TAILINGS ELEVATOR
	500697	BEARING ASSY
	500698	HUB
	500760	SICKLE SECTION
	500786	SICKLE BAR BLANK
	500983	BUSHING
	501047	BEARING
	501060	SLAT STRAW RACK
	501143	LINK
	501167	BLOCK
	501186	FRAM ASSY RH
	501187	FLOATING FRAME SIDE ASSY
	501200	TAILINGS SCREEN BLANK
	501201	BOLT
	501211	SPRING
	501258	CAP
	501292	U-JOINT
	501294	SPRING
	501377	FACING
	501423	BLOCK ASSY
	501471	BUCKET
	501518	BEARING AUGER
	501603	PLATE
	501620	BRACKET
	501623	BLOCK HANGER
	501652	CLEAN SHOE SIDE
	501653	CLEAN SHOE SIDE
	501717	BOOT
	501730	BEARING ASSY

## AllCropHarvester.com Parts List

60 Harvester	501790	DEFLECTOR LARGE
	501804	HANGER
	501828	HEAD
	501835	BLOCK
	501879	BUSHING
	501888	GREASE SEAL
	501890	UBOLT
	501904	SHELLING PLATE
	501920	BEARING
	501930	GRAIN CONVEYOR COVER
	501934	BEARING HOUSING CYLINDER
	501940	PIN
	501941	BEARING
	501947	DISC
	501948	BEARING ASSY
	501950	AUGER ASSY
	501968	SPOUT
	502390	GUIDE
	502394	DECAL
	502432	BELT CYLINDER DRIVE OBSOLETE
	502436	BELT
	502437	BELT UNLOADING
	502438	BELT STRAW SPREADER
	502669	DIVIDER
	502670	DIVIDER
	503354	SICKLE FILLER
	503746	PIN
	503781	VALVE BAGGER
	503786	REEL LIFT LATCH
	503841	GRAIN CONVEYOR AUGER
	503938	PAWL
	504007	PLATE REINFORCING
	504196	DIVIDER BASE LH
	504633	HOUSING
	505234	PIN HEADER LIFT
	505236	DETENT HAND HEADER LIFT
	505650	SLINGER
	505817	QUADRANT HEADER LIFT
	506483	BEARING ASSY
	506633	END PITMAN
	506634	PITMAN END UPPER
	506931	SHEAVE GEAR BOX
	506968	BUSHING
	507019	SHEAVE

## AllCropHarvester.com Parts List

60 Harvester	507060	BEARING
	507088	SHIM
	507116	SNAP RING
	507128	BRACKET HEADER PIVOT RH
	507129	BRACKET HEADER PIVOT LH
	507177	PITMAN
	507189	WOOD CHAIN GUIDE
	507191	WOOD CHAIN GUIDE
	507192	SPROCKET
	507194	CLUTH RING
	507220	BEARING
	507223	BEARING
	507223	BALL BEARING CYLINDER SEALED
	507225	BEARING ROLLER
	507226	BEARING ROLLER
	507252	DIVIDER EXTENSION
	507265	CLUTCH ASSY
	507273	SPRING
	507304	END SHEET
	507327	GRAIN SHIELD
	507328	GRAIN SHIELD
	507344	BUSHING
	507389	SPROCKET SPECIAL
	507472	SLAT ASSEMBLY
	507628	LAGGING
	508625	HUB IDLER SHEAVE
	508920	SUPPORT
	508921	HOUSING
	508934	BEARING LOWER DRAPER
	508973	PAWL RATCHET
	508974	PAWL LEVER
	510215	SPROCKET
	510239	HOUSING
	510310	COLLAR
	510313	BEARING BALL
	510314	SEAL CYLINDER
	510340	CAP
	510341	SHEAVE
	510378	DECAL
	510402	GUIDE
	510526	ROLLER BEARING
	510527	RACE
	510741	JAW
	511145	ROD

## AllCropHarvester.com Parts List

60 Harvester	511328	SPRING
	511379	CLIP
	511870	SLIDE
	512037	FAN BLADE
	512140	CAP
	512142	SICKLE PIVOT PIN
	512148	BEARING
	512151	PLATE
	512164	BEARING - LOWER DRAPER ROLLER
	512230	PTO JOINT ASSY
	512235	HANDEL
	512335	PIVOT
	512562	GRAIN SHIELD
	512563	GRAIN SHIELD
	512566	YOKE PTO
	513371	BRACE
	513516	SWIVEL
	513658	BAR
	513926	CLUTCH
	514632	SHEAVE
	515189	ROCKER ASSY
	515190	BELL SICKLE CRANK
	515674	RING
	516026	SPRING
	516090	COLLAR
	516561	SHIFTER
	517136	COLLAR
	517259	SPROCKET 7 TOOTH
	517589	BUSHING FLOATING FRAME
	517745	BAT
	517754	SHEAVE
	517806	SPROCKET
	517860	DECAL
	517951	SPROCKET 7 TEETH
	517966	SPROCKET 8 TOOTH
	517967	SPROCKET 9T
	518537	FAN SPOKE
	519446	CLIP
	519447	SPRING
	519448	HITCH ASSY
	519835	BUSHING
	524141	CYLINDER SHEAVE
	526372	AUGER CLEAN GRAIN
	526374	SHAFT

## AllCropHarvester.com Parts List

60 Harvester	535485	HUB
	535496	HEAD
	535533	RUBBER
	535537	GUIDE
	535546	SHIM GEAR COVER
	535547	SHIM TUBE
	535563	HUB
	535564	HOLD DOWN
	535567	LINK ATTACHING
	535568	LINK ATTACHING
	540445	LINING SLIP CLUTCH
	540498	GUARD HEADER GRAIN
	540672	HEADER PIVOT
	540729	WOOD CHAIN GUIDE
	543132	CHAIN #55
	905126	KEY WOODRUFF
	910192	PIN SHEAR
	910315	KEY
	910317	KEY
	910516	RIVET
	915701	RIVET
	917148	BALL
	C5D-1511	BEARING
	C5D-1644	HANGER
	C5D-1645	HANGER STRAW RACK REAR
	C5D-1654	GRAIN DRAG TENSIONER
	C5D-1680	BEARING
	C5D-1727	SPROCKET
	D5D-1701	HOLD DOWN
	K5D-14894	BUSHING
	R-501730	REPLACEMENT FOR 501730
	R5D-14539	SLIDE
	S5D-16118	KEY
	501212	FINGER
	501493	SEAL
	500327	PLATE
	503954	SPRING
	509065	BUSHING
	500497	PIN



## AllCropHarvester.com Parts List

60A Harvester		
	200189	SPRING
	YAC521	CONCAVE PATCH
	200309	SEAL
	211227	BALL BEARING
	500250	PIN
	500346	BEARING GRAIN ELEVATOR
	500369	CAP
	500501	CAP
	500502	SEAL
	500686	PLATE TAILINGS ELEVATOR
	500968	HUB
	500760	SICKLE SECTION
	500786	SICKLE BAR BLANK
	501047	BEARING
	501060	SLAT STRAW RACK
	501143	LINK
	501167	BLOCK
	501186	FRAM ASSY RH
	501187	FLOATING FRAME SIDE ASSY
	501200	TAILINGS SCREEN BLANK
	501201	BOLT
	501211	SPRING
	501258	CAP
	501294	SPRING
	501423	BLOCK ASSY
	501471	BUCKET
	501518	BEARING AUGER
	501603	PLATE
	501620	BRACKET
	501623	BLOCK HANGER
	501652	CLEAN SHOE SIDE
	501653	CLEAN SHOE SIDE
	501730	BEARING ASSY
	501790	DEFLECTOR LARGE
	501804	HANGER
	501828	HEAD
	501879	BUSHING
	501890	UBOLT
	501904	SHELLING PLATE
	501920	BEARING
	501930	GRAIN CONVEYOR COVER
	501940	PIN
	501941	BEARING

## AllCropHarvester.com Parts List

60A Harvester	501947	DISC
	501948	BEARING ASSY
	501950	AUGER ASSY
	502390	GUIDE
	502394	DECAL
	502436	BELT
	502437	BELT
	502438	BELT STRAW SPREADER
	502669	DIVIDER
	502670	DIVIDER
	503354	SICKLE FILLER
	503746	PIN
	503781	VALVE BAGGER
	503786	REEL LIFT LATCH
	503841	GRAIN CONVEYOR AUGER
	503938	PAWL
	504007	PLATE REINFORCING
	504196	DIVIDER BASE LH
	504633	HOUSING
	505234	PIN HEADER LIFT
	505236	DETENT HAND HEADER LIFT
	505650	SLINGER
	505817	QUADRANT HEADER LIFT
	506633	END PITMAN
	506634	PITMAN END UPPER
	506931	SHEAVE GEAR BOX
	507019	SHEAVE
	507060	BEARING
	507088	SHIM
	507116	SNAP RING
	507128	BRACKET HEADER PIVOT RH
	507129	BRACKET HEADER PIVOT LH
	507177	PITMAN
	507189	WOOD CHAIN GUIDE
	507191	WOOD CHAIN GUIDE
	507192	SPROCKET
	507194	CLUTH RING
	507220	BEARING
	507223	BEARING
	507225	BEARING ROLLER
	507226	BEARING ROLLER
	507252	DIVIDER EXTENSION
	507265	CLUTCH ASSY
	507273	SPRING

## AllCropHarvester.com Parts List

60A Harvester	507304	END SHEET
	507327	GRAIN SHIELD
	507328	GRAIN SHIELD
	507344	BUSHING
	507389	SPROCKET SPECIAL
	507472	SLAT ASSEMBLY
	507628	LAGGING
	508625	HUB IDLER SHEAVE
	508920	SUPPORT
	508921	HOUSING
	508973	PAWL RATCHET
	508974	PAWL LEVER
	510215	SPROCKET
	510239	HOUSING
	510310	COLLAR
	510313	BEARING BALL
	510314	SEAL CYLINDER
	510340	CAP
	510341	SHEAVE
	510378	DECAL
	510402	GUIDE
	510526	ROLLER BEARING
	510527	RACE
	510741	JAW
	511145	ROD
	511328	SPRING
	511379	CLIP
	511870	SLIDE
	512037	FAN BLADE
	512140	CAP
	512142	SICKLE PIVOT PIN
	512148	BEARING
	512151	PLATE
	512164	BEARING - LOWER DRAPER ROLLER
	512230	PTO JOINT ASSY
	512235	HANDEL
	512269	HUB CAP
	512270	CAP WHELL HUB
	512335	PIVOT
	512562	GRAIN SHIELD
	512563	GRAIN SHIELD
	512566	YOKE PTO
	513371	BRACE
	513516	SWIVEL

## AllCropHarvester.com Parts List

60A Harvester	513658	BAR
	513703	GASKET
	513926	CLUTCH
	515189	ROCKER ASSY
	515190	BELL SICKLE CRANK
	515674	RING
	516026	SPRING
	516090	COLLAR
	516561	SHIFTER
	517097	HUB GEAR BOX
	517136	COLLAR
	517259	SPROCKET 7 TOOTH
	517745	BAT
	517748	PLATE
	517754	SHEAVE
	517860	DECAL
	517951	SPROCKET 7 TEETH
	517965	SHEAVE
	517966	SPROCKET 8 TOOTH
	517967	SPROCKET 9T
	518537	FAN SPOKE
	519446	CLIP
	519447	SPRING
	519448	HITCH ASSY
	519835	BUSHING
	524141	CYLINDER SHEAVE
	526372	AUGER CLEAN GRAIN
	526374	SHAFT
	535485	HUB
	535496	HEAD
	535533	RUBBER
	535537	GUIDE
	535563	HUB
	535564	HOLD DOWN
	535567	LINK ATTACHING
	535568	LINK ATTACHING
	540498	GUARD HEADER GRAIN
	905126	KEY WOODRUFF
	910192	PIN SHEAR
	910315	KEY
	910317	KEY
	910516	RIVET
	915701	RIVET
	917148	BALL

## AllCropHarvester.com Parts List

60A Harvester	C5D-1511	BEARING
	C5D-1644	HANGER
	C5D-1645	HANGER STRAW RACK REAR
	C5D-1654	GRAIN DRAG TENSIONER
	C5D-1680	BEARING
	C5D-1727	SPROCKET
	K5D-14748	SHIM TUBE
	K5D-14789	SHIM GEAR COVER
	MA-304	CHAIN #55
	R-501730	REPLACEMENT FOR 501730
	R5D-14539	SLIDE
	S5D-16118	KEY
	YAC521	CONCAVE PATCH
	501212	FINGER
	501493	SEAL
	503954	SPRING
	500497	PIN

## AllCropHarvester.com Parts List

66 Harvester		
	200189	SPRING
	200309	SEAL
	211227	BALL BEARING
	500250	PIN
	500346	BEARING GRAIN ELEVATOR
	500369	CAP
	500501	CAP
	500502	SEAL
	500686	PLATE TAILINGS ELEVATOR
	500698	HUB
	500760	SICKLE SECTION
	500983	Bushing
	501047	BEARING
	501060	SLAT STRAW RACK
	501167	BLOCK
	501186	FRAM ASSY RH
	501187	FLOATING FRAME SIDE ASSY
	501200	TAILINGS SCREEN BLANK
	501201	BOLT
	501211	SPRING
	501258	CAP
	501294	SPRING
	501423	BLOCK ASSY
	501471	BUCKET
	501518	BEARING AUGER
	501603	PLATE
	501623	BLOCK HANGER
	501652	CLEAN SHOE SIDE
	501653	CLEAN SHOE SIDE
	501730	BEARING ASSY
	501804	HANGER
	501828	HEAD
	501835	BLOCK
	501879	BUSHING
	501888	GREASE SEAL
	501890	UBOLT
	501904	SHELLING PLATE
	501920	BEARING
	501930	GRAIN CONVEYOR COVER
	501940	PIN
	501941	BEARING
	501947	DISC
	501948	BEARING ASSY

## AllCropHarvester.com Parts List

66 Harvester	501950	AUGER ASSY
	501968	SPOUT
	502390	GUIDE
	502394	DECAL
	502436	BELT
	502438	BELT STRAW SPREADER
	502669	DIVIDER
	502670	DIVIDER
	503354	SICKLE FILLER
	503746	PIN
	503781	VALVE BAGGER
	503786	REEL LIFT LATCH
	503841	GRAIN CONVEYOR AUGER
	503938	PAWL
	504007	PLATE REINFORCING
	504066	BLOCK SLIDE
	504196	DIVIDER BASE LH
	504633	HOUSING
	505234	PIN HEADER LIFT
	505236	DETENT HAND HEADER LIFT
	505650	SLINGER
	505817	QUADRANT HEADER LIFT
	506633	END PITMAN
	506634	PITMAN END UPPER
	506968	BUSHING
	507019	SHEAVE
	507060	BEARING
	507088	SHIM
	507116	SNAP RING
	507128	BRACKET HEADER PIVOT RH
	507129	BRACKET HEADER PIVOT LH
	507177	PITMAN
	507189	WOOD CHAIN GUIDE
	507191	WOOD CHAIN GUIDE
	507192	SPROCKET
	507194	CLUTH RING
	507220	BEARING
	507223	BEARING
	507225	BEARING ROLLER
	507226	BEARING ROLLER
	507265	CLUTCH ASSY
	507273	SPRING
	507327	GRAIN SHIELD
	507328	GRAIN SHIELD

## AllCropHarvester.com Parts List

66 Harvester	507344	BUSHING
	507389	SPROCKET SPECIAL
	507472	SLAT ASSEMBLY
	507628	LAGGING
	508625	HUB IDLER SHEAVE
	508920	SUPPORT
	508921	HOUSING
	508973	PAWL RATCHET
	508974	PAWL LEVER
	510215	SPROCKET
	510239	HOUSING
	510310	COLLAR
	510313	BEARING BALL
	510314	SEAL CYLINDER
	510340	CAP
	510341	SHEAVE
	510378	DECAL
	510402	GUIDE
	510526	ROLLER BEARING
	510527	RACE
	510741	JAW
	511145	ROD
	511238	BUSHING
	511328	SPRING
	511379	CLIP
	511870	SLIDE
	512037	FAN BLADE
	512140	CAP
	512142	SICKLE PIVOT PIN
	512148	BEARING
	512151	PLATE
	512164	BEARING - LOWER DRAPER ROLLER
	512230	PTO JOINT ASSY
	512269	HUB CAP
	512270	CAP WHELL HUB
	512562	GRAIN SHIELD
	512563	GRAIN SHIELD
	512566	YOKE PTO
	513516	SWIVEL
	513658	RUBBER
	513703	GASKET
	513836	SICKLE BAR BLANK
	513858	SHIELD WOOD
	513907	BAT



## AllCropHarvester.com Parts List

66 Harvester	513926	CLUTCH
	515674	RING
	516026	SPRING
	516090	COLLAR
	516561	SHIFTER
	517097	HUB GEAR BOX
	517136	COLLAR
	517259	SPROCKET 7 TOOTH
	517589	BUSHING FLOATING FRAME
	517748	PLATE
	517754	SHEAVE
	517806	SPROCKET
	517860	DECAL
	517951	SPROCKET 7 TEETH
	517965	SHEAVE
	517966	SPROCKET 8 TOOTH
	517967	SPROCKET 9T
	518537	FAN SPOKE
	519446	CLIP
	519447	SPRING
	519448	HITCH ASSY
	519835	BUSHING
	519979	ARM
	519991	BRACKET
	521513	DEFLECTOR LARGE
	521541	BEARING
	523202	BELT STRAW CHOPPER
	523627	GRAIN TANK DOOR
	523641	BOTTOM TANK UNLOADING AUGER
	524000	BEARING SICKLE PITMAN
	524139	SHEAVE GEAR BOX
	524141	CYLINDER SHEAVE
	526372	AUGER CLEAN GRAIN
	526374	SHAFT
	526381	DEFLECTOR CYLINDER HOUSING
	528518	BALL BEARING CYLINDER SEALED
	528811	HOUSING
	531213	GRAIN DRAG TENSIONER
	535483	BEARING
	535485	HUB
	<del>535487</del>	<del>BEARING</del>
	535489	SPROCKET
	535496	HEAD
	535516	KEY

## AllCropHarvester.com Parts List

66 Harvester	535533	RUBBER
	535537	GUIDE
	535546	SHIM GEAR COVER
	535547	SHIM TUBE
	535563	HUB
	535564	HOLD DOWN
	535565	HANGER STRAW RACK REAR
	535566	HANGER
	535567	LINK ATTACHING
	535568	LINK ATTACHING
	538302	SPROCKET
	543132	CHAIN #55
	905126	KEY WOODRUFF
	910192	PIN SHEAR
	910315	KEY
	910317	KEY
	910516	RIVET
	915701	RIVET
	917148	BALL
	R-501730	REPLACEMENT FOR 501730
	S5D-16118	KEY
	YAC521	CONCAVE PATCH
	501493	SEAL
	500497	PIN

## AllCropHarvester.com Parts List

72 Harvester		
	YAC521	CONCAVE PATCH
	200189	SPRING
	200309	SEAL
	500250	PIN
	500346	BEARING GRAIN ELEVATOR
	500369	CAP
	500501	CAP
	500502	SEAL
	500686	PLATE TAILINGS ELEVATOR
	500698	HUB
	500760	SICKLE SECTION
	500983	BUSHING
	501047	BEARING
	501060	SLAT STRAW RACK
	501167	BLOCK
	501200	TAILINGS SCREEN BLANK
	501201	BOLT
	501211	SPRING
	501294	SPRING
	501423	BLOCK ASSY
	501471	BUCKET
	501603	PLATE
	501623	BLOCK HANGER
	501652	CLEAN SHOE SIDE
	501653	CLEAN SHOE SIDE
	501730	BEARING ASSY
	501804	HANGER
	501828	HEAD
	501835	BLOCK
	501879	BUSHING
	501888	GREASE SEAL
	501890	UBOLT
	501904	SHELLING PLATE
	501920	BEARING
	501930	GRAIN CONVEYOR COVER
	501940	PIN
	501941	BEARING
	501947	DISC
	501948	BEARING ASSY
	501950	AUGER ASSY
	502394	DECAL
	503781	VALVE BAGGER
	503841	GRAIN CONVEYOR AUGER

## AllCropHarvester.com Parts List

72 Harvester	504007	PLATE REINFORCING
	504066	BLOCK SLIDE
	505650	SLINGER
	507116	SNAP RING
	507177	PITMAN
	507189	WOOD CHAIN GUIDE
	507191	WOOD CHAIN GUIDE
	507192	SPROCKET
	507194	CLUTH RING
	507220	BEARING
	507223	BEARING
	507226	BEARING ROLLER
	507265	CLUTCH ASSY
	507266	ROLLER BEARING
	507327	GRAIN SHIELD
	507328	GRAIN SHIELD
	507344	BUSHING
	507389	SPROCKET SPECIAL
	507472	SLAT ASSEMBLY
	507628	LAGGING
	507965	BELT REEL DRIVE OUTER
	508920	SUPPORT
	508921	HOUSING
	508973	PAWL RATCHET
	508974	PAWL LEVER
	510239	HOUSING
	510310	COLLAR
	510313	BEARING BALL
	510314	SEAL CYLINDER
	510340	CAP
	510341	SHEAVE
	510402	GUIDE
	510526	ROLLER BEARING
	510527	RACE
	510741	JAW
	511379	CLIP
	511870	SLIDE
	512037	FAN BLADE
	512562	GRAIN SHIELD
	512563	GRAIN SHIELD
	512566	YOKE PTO
	513658	BAR
	515674	RING
	516026	SPRING

## AllCropHarvester.com Parts List

72 Harvester	516090	COLLAR
	516561	SHIFTER
	517097	HUB GEAR BOX
	517259	SPROCKET 7 TOOTH
	517754	SHEAVE
	517806	SPROCKET
	517860	DECAL
	517951	SPROCKET 7 TEETH
	517965	SHEAVE
	517966	SPROCKET 8 TOOTH
	517967	SPROCKET 9T
	518537	FAN SPOKE
	519446	CLIP
	519447	SPRING
	519448	HITCH ASSY
	520634	DIVIDER
	520668	HOLD DOWN
	521062	HUB
	521316	SLIDE
	521513	DEFLECTOR LARGE
	521541	BEARING
	523202	BELT STRAW CHOPPER
	523627	GRAIN TANK DOOR
	523641	BOTTOM TANK UNLOADING AUGER
	523979	ARM
	524139	SHEAVE GEAR BOX
	524141	CYLINDER SHEAVE
	526372	AUGER CLEAN GRAIN
	526374	SHAFT
	526381	DEFLECTOR CYLINDER HOUSING
	526434	ROCKER ARM
	527068	BUSHING
	528518	BALL BEARING CYLINDER SEALED
	528811	HOUSING
	531213	GRAIN DRAG TENSIONER
	533147	GUIDE
	533260	HUB SICKLE LINK
	533261	BUSHING RUBBER
	533262	STUD
	533279	SPROCKET
	533400	BELT HEADER DRIVE
	533434	GUIDE
	533444	DIVIDER
	533448	SICKLE GUIDE

## AllCropHarvester.com Parts List

72 Harvester	534259	RETAINER OUTER
	534260	RETAINER INNER
	534261	BLOCK
	534282	BEARING ASSY
	535483	BEARING
	535485	HUB
	535487	BEARING
	535489	SPROCKET
	535516	KEY
	535533	RUBBER
	535537	GUIDE
	535546	SHIM GEAR COVER
	535547	SHIM TUBE
	535563	HUB
	535565	HANGER STRAW RACK REAR
	535566	HANGER
	535567	LINK ATTACHING
	535568	LINK ATTACHING
	538286	SHIM
	538288	RETAINER
	538302	SPROCKET
	539105	PTO JOINT ASSY
	543132	CHAIN #55
	805050	BALL BEARING
	905126	KEY WOODRUFF
	910192	PIN SHEAR
	910315	KEY
	910317	KEY
	910516	RIVET
	911240	RIVET
	915701	RIVET
	917148	BALL
	921019	PIN
	1113372	ROLLER BEARING
	1113373	BEARING W/COLLAR
	533143S	SICKLE BAR(BLANK)
	R-501730	REPLACEMENT FOR 501730
	YAC521	CONCAVE PATCH
	500497	PIN

## AllCropHarvester.com Parts List

90 Harvester		
	500760	SICKLE SECTION
	501294	SPRING
	501941	BEARING
	503304	BELT STRAW SPREADER LONG
	504066	BLOCK SLIDE
	507116	SNAP RING
	507266	ROLLER BEARING
	507220	BEARING
	507223	BEARING
	507225	BEARING ROLLER
	510239	HOUSING
	510313	BALL BEARING
	510741	JAW
	511002	HUB
	512164	ROLLER BEARING
	511379	CLIP
	516090	COLLAR
	517259	SPROCKET 7 TOOTH
	517806	SPROCKET
	517951	SPROCKET 7 TEETH
	517965	SHEAVE
	519446	CLIP
	520899	BLOCK
	521062	HUB
	521541	BEARING
	523627	GRAIN TANK DOOR
	524000	BEARING
	526990	BUSHING
	527068	BUSHING
	527321	BUSHING
	527322	BUSHING RUBBER HANGER
	527336	BUSHING
	528518	BALL BEARING
	528811	HOUSING
	535516	KEY
	535533	RUBBER
	535537	GUIDE
	538286	SHIM
	538288	RETAINER
	538302	SPROCKET
	539105	PTO JOINT ASSY
	501493	SEAL
	503954	SPRING

## AllCropHarvester.com Parts List



## AllCropHarvester.com Parts List

SP100 Harvester		
	501294	SPRING
	507223	BEARING
	507266	ROLLER BEARING
	510239	HOUSING
	510313	BALL BEARING
	510340	CAP
	510526	ROLLER BEARING
	510527	RACE
	511379	CLIP
	511878	SEAL
	512164	ROLLER BEARING
	516090	COLLAR
	517136	COLLAR
	528518	BALL BEARING
	503954	SPRING

## AllCropHarvester.com Parts List

Roto Baler		
	539105	PTO JOINT ASSY
	500983	BUSHING
	503304	BELT DRIVE
	507223	BEARING
	508264	GEAR
	508295	BEARING SAME AS 533252
	508677	LEVER
	508770	GEAR
	509137	PIN
	509156	PLUNGER
	509167	PIVOT PIN
	509513	KNIFE
	509524	SPRING
	509550	SLAT ASSY
	510222	COLLAR
	510245	SPROCKET
	510741	JAW
	510819	STUD
	510994	ROLLER
	511002	HUB
	511344	HOUSING
	511878	SEAL
	512008	BEARING
	512177	SPROCKET
	512177	SPROCKET
	512840	SEAL
	512882	BUSHING WHEEL
	516136	SPROCKET
	516137	SPROCKET 8T
	519446	CLIP
	519448	HITCH ASSY
	523290	SLAT ASSY
	523290	SLAT ASSY
	533247	SPROCKET
	533247	SPROCKET
	533252	BEARING SAME AS 508295
	533259	PTO SPRING
	520545	BAR CONCAVE
	521062	HUB
	521982	AUGER
	524000	BEARING
	525216	HUB

## AllCropHarvester.com Parts List

<b>Roto Baler</b>		
	502919	PIN
	509500	PLATE
	501212	FINGER
	501493	SEAL

## AllCropHarvester.com Parts List

Forage Harvester		
	500983	BUSHING
	501212	FINGER
	502344	CAP
	502670	DIVIDER
	503160	PITMAN
	503354	SICKLE FILLER
	504196	DIVIDER BASE LH
	504199	ROLLER ASSY
	504232	DRAPER SLAT
	505968	TINE
	510313	BALL BEARING
	510340	CAP
	510526	ROLLER BEARING
	510527	RACE
	510741	JAW
	511176	BELT
	511232	SICKLE ASSY
	512164	ROLLER BEARING
	511328	SPRING
	512269	HUB CAP
	512375	HOLD DOWN
	514632	SHEAVE
	514875	RUBBER BUSHING
	514903	WOOD ARM
	514908	BELT
	514909	BELT
	514910	BELT
	515768	BELT
	519007	BELT
	519392	GUARD
	519448	HITCH ASSY
	523362	BAT
	535537	RUB PLATE
	533259	PTO SPRING
	539105	PTO JOINT ASSY
	503954	SPRING
	502324	SNAP RING
	500497	PIN
	501034	SPRING

## AllCropHarvester.com Parts List

<b>Gleaner Special Attachment</b>		
	519007	BELT
<b>Moldboard Plow</b>		
	308308	COULTER
<b>Rotary Mower</b>		
	539105	PTO JOINT ASSY
<b>Unknown</b>		
	503308	BELT
	503459	BELT
	512759	BELT
	604431	ROLLER BEARING
	802154	ROD
	802171	BELT
	1116256	WOOD
	504080	WOOD BLOCK
<b>WC/RC Mower</b>	802932	PITMAN
<b>303 Baler</b>	511002	HUB
	503954	SPRING
	502324	SNAP RING
<b>56 Flail Mower</b>	517343	BLADE
<b>Sickle Mower</b>	SWATHBOARDSHAFT	
<b>Side Dresser</b>	511504	BEARING
	501212	FINGER
<b>Windrower</b>	500326	STRAP
	500325	HINGE
	501212	FINGER
	500327	PLATE
	503954	SPRING
	502324	SNAP RING
<b>1 Row Corn Picker</b>	501212	FINGER
	503954	SPRING
	502324	SNAP RING