

New Old Stock Allis-Chalmers Implement Parts. 12/2020 Rev 1

KAS LLC. sales@allcropharvester.com 330-469-9301

<u>Part</u>	<u>Qty</u>	<u>Desc</u>
200189	5	SPRING, DETENT
200309	21	SEAL
206531	1	BUSHING
209292	1	BEARING
209889	1	CONE
210551	1	CUP
300728	1	CLUTCH PIECE
306329	3	SPACER
308300	3	GUIDE
308308	1	COULTER
308956	2	BRACKET
309457	1	CLUTCH PIECE
310468	2	BALL BEARING
310471	1	BALL BEARING
313664	1	BRACE
314585	2	ROD
317947	1	COLLAR
320373	4	HITCH PIN
321902	1	SPACER
340424	1	SPRING
342106	3	PLUNGER
500178	2	REINFORCEMENT
500250	10	PIN
500322	3	BAT
500323	10	ARM REEL
500325	10	HINGE
500326	1	STRAP
500327	8	PLATE
500332	7	BAT
500346	1	BEARING GRAIN ELEVATOR
500369	3	CAP
500416	2	BEARING
500497	1	PIN
500501	2	CAP, GREASE SEAL
500502	47	SEAL, AXLE
500517	11	SPACER
500686	1	PLATE TAILINGS ELEVATOR
500697	2	BEARING ASSY
500698	5	HUB, CLUTCH
500700	1	BEARING FAN
500711	1	SPROCKET
500983	48	BUSHING

501034	4 SPRING
501047	6 BEARING
501060	12 SLAT STRAW RACK
501143	1 LINK, PITMAN
501167	97 BLOCK, TAILINGS PADDLE
501186	1 FRAM ASSY RH
501200	1 TAILINGS SCREEN BLANK
501201	13 BOLT, GRAIN DRAG PIVOT
501211	1 SPRING
501212	2 FINGER
501258	8 CAP
501292	1 U-JOINT
501294	2 SPRING
501377	1 FACING, UNLOADING GEAR
501423	23 BLOCK ASSY
501471	163 BUCKET, GRAIN ELEVATOR
501493	3 SEAL
501518	1 BEARING AUGER
501603	11 PLATE, SEPERATOR
501620	1 BRACKET, STRAW RACK
501623	7 BLOCK HANGER
501652	1 CLEAN SHOE SIDE
501653	1 CLEAN SHOE SIDE
501717	1 BOOT, UNLOADING AUGER
501730	1 BEARING ASSY
501804	1 HANGER, CHAFFER
501828	1 HEAD, FRONT GRAIN ELEVATOR
501835	4 BLOCK
501879	1 BUSHING
501888	22 GASKET
501890	1 UBOLT
501904	2 SHELLING PLATE
501930	3 GRAIN CONVEYOR COVER
501934	1 BEARING HOUSING CYLINDER
501940	1 PIN, SHEAR
501947	11 DISC, REMOVABLE AUGER
501948	1 BEARING ASSY
501950	2 AUGER ASSY
501968	1 SPOUT, UNLOADING AGUER
501989	2 BRACE
502324	2 SNAP RING
502344	1 CAP
502383	10 PIN
502394	58 DECAL SEP DRIVE
502432	1 BELT
502437	1 BELT
502438	1 BELT

502669	1 DIVIDER
502670	5 DIVIDER
502919	11 PIN
503020	1 AUGER
503071	1 GRAIN ELEVATOR RADDLE ASSY
503155	2 BEARING WOODEN
503160	1 PITMAN
503188	1 ROLL
503304	2 BELT
503306	2 BELT
503354	12 SICKLE FILLER
503459	2 BELT
503549	8 SEAL
503621	1 SPROCKET
503746	4 PIN
503771	2 BUSHING WOOD
503781	1 VALVE BAGGER
503786	1 REEL LIFT LATCH
503799	1 SPROCKET 9T
503938	1 PAWL
503954	1 SPRING
504007	21 PLATE REINFORCING
504079	1 PTIMAN
504093	1 BELT
504177	7 BAR CONCAVE
504196	1 DIVIDER BASE LH
504199	1 ROLLER ASSY
504232	19 DRAPER SLAT
504233	13 GRAIN ELEVATOR BUCKET
504419	3 SPROCKET
504423	3 SPROCKET
504633	3 HOUSING, DETENT
504721	29 BAR, CYLINDER
505234	5 PIN HEADER LIFT
505236	13 DETENT HAND HEADER LIFT
505237	1 CHANNEL
505650	2 SLINGER
505817	5 QUADRANT HEADER LIFT
505826	5 BUSHING
505968	16 TINE
506483	2 BEARING ASSY
506633	5 END PITMAN
506634	2 PITMAN END UPPER
506878	1 ROCKER BEARING
506968	22 BUSHING
507019	1 SHEAVE
507060	1 BEARING, LOWER DRAPER IDLER

507088	1 SHIM
507103	1 HOUSING
507116	4 SNAP RING
507128	1 BRACKET HEADER PIVOT RH
507129	1 BRACKET HEADER PIVOT LH
507181	8 SHEAVE
507190	1 BLOCK
507191	2 WOOD CHAIN GUIDE
507192	1 SPROCKET
507223	2 BEARING, BALL
507225	4 BEARING ROLLER
507226	1 BEARING ROLLER
507229	1 CONE BEARING
507252	1 DIVIDER EXTENSION
507265	2 CLUTCH ASSY
507266	1 ROLLER BEARING
507273	1 SPRING
507304	1 END SHEET
507327	5 GRAIN SHIELD
507328	2 GRAIN SHIELD
507344	41 BUSHING
507389	1 SPROCKET SPECIAL
507452	3 BEARING, ROLLER
507472	1 SLAT ASSEMBLY
507621	1 HOUSING
507628	10 LAGGING, RUBBER
507885	2 RING
508264	1 GEAR
508295	5 BEARING
508491	4 HOUSING
508492	1 DRUM
508625	1 HUB IDLER SHEAVE
508677	2 LEVER
508768	1 PINION
508770	4 GEAR
508920	1 SUPPORT, PTO TRUNNION
508921	2 HOUSING
508934	1 BEARING LOWER DRAPER
508951	2 HUB SICKLE DRIVE
508973	2 PAWL RATCHET
508974	1 PAWL LEVER
509048	2 SHEAVE ASSY
509065	11 BUSHING
509136	8 PIN
509137	20 PIN
509146	10 BOLT
509147	2 PIN

509156	16 PLUNGER
509167	10 PIVOT PIN
509500	6 PLATE
509513	20 KNIFE
509524	5 SPRING
509534	21 SPRING
509550	22 SLAT ASSY
510049	1 STONE
510215	2 SPROCKET, REEL
510222	1 COLLAR
510236	1 CAP CYLINDER HOUSING RH
510239	1 HOUSING
510244	2 SPROCKET
510245	5 SPROCKET
510310	2 COLLAR
510313	2 BEARING BALL
510314	5 SEAL CYLINDER
510340	2 CAP
510341	2 SHEAVE
510378	39 DECAL HEADER DRIVE
510402	5 GUIDE, BELT
510526	5 ROLLER BEARING
510527	1 RACE
510589	1 HOUSING ASSY
510614	6 PLATE
510619	3 CLUTCH
510685	2 PIN
510741	1 JAW
510816	6 ROLLER
510819	7 STUD
510868	1 BRACKET
510879	1 ARM
510994	1 ROLLER
511002	1 HUB
511065	10 LATCH
511085	1 SPRING
511145	2 ROD
511176	1 BELT
511232	3 SICKLE ASSY
511238	100 BUSHING, CONNECTING LINK,RUBBER
511328	3 SPRING
511344	2 HOUSING
511385	1 SPRING
511504	4 BEARING
511508	2 CLIP
511540	2 SHAFT
511870	1 SLIDE, BEARING

511878	2 SEAL
512008	2 BEARING
512037	1 FAN BLADE
512140	1 CAP,BEARING
512142	5 SICKLE PIVOT PIN
512148	1 BEARING
512164	3 BEARING
512177	6 SPROCKET
512188	4 PIN
512209	1 BRACKET
512230	2 PTO JOINT ASSY
512235	1 HANDEL, HEADER LIFT
512236	1 HANDLE BRACKET
512269	3 HUB CAP
512270	2 CAP WHELL HUB
512282	7 SICKLE LINK
512335	1 PIVOT
512374	3 GUARD
512375	7 HOLD DOWN, SICKLE
512376	3 SICKLE CLIP
512562	3 GRAIN SHIELD
512563	1 GRAIN SHIELD
512566	1 YOKE PTO
512679	2 BELT
512759	3 BELT
512840	4 SEAL
512882	6 BUSHING WHEEL
513109	4 HUB
513357	3 BLOCK, CHAIN,WOOD
513371	1 BRACE, REEL
513485	10 PIN
513686	3 DECAL "66"
513703	2 GASKET
513768	1 SPROCKET 6T
513836	3 SICKLE BAR BLANK
513858	1 SHIELD WOOD
513907	1 BAT
513926	1 CLUTCH
514632	5 SHEAVE
514875	14 RUBBER BUSHING
514903	4 WOOD ARM, REEL
514908	1 BELT
514909	2 BELT
514910	2 BELT
515189	1 ROCKER ASSY
515190	2 BELL SICKLE CRANK
515217	3 GUARD SICKLE

515674	1 RING W/512010
515768	1 BELT
515769	2 LINK ATTACHING RH
516026	2 SPRING, CLUTCH, USED WHEN SK
516090	1 COLLAR
516136	3 SPROCKET
516137	1 SPROCKET 8T
516449	1 BAR
516561	1 SHIFTER
517096	5 DECAL 60
517097	3 HUB GEAR BOX
517136	2 COLLAR
517259	3 SPROCKET 7 TOOTH
517279	9 DECAL ALL-CROP HARVESTER
517316	7 LATCH
517343	2 BLADE
517589	1 BUSHING
517610	1 CONCAVE
517655	1 SHEAVE
517691	2 SHEAVE
517748	48 PLATE,BOLT
517754	1 SHEAVE
517806	2 SPROCKET
517860	35 DECAL CYLINDER SPEED
517930	3 BEARING ASSY
517950	4 ROLLER BEARING
517951	2 SPROCKET 7 TEETH
517956	1 SPROCKET
517961	1 HUB
517966	2 SPROCKET 8 TOOTH
518537	2 FAN SPOKE
518538	1 HANDLE
518878	7 BLOCK
519007	1 BELT
519392	6 GUARD
519444	1 HITCH PLATE
519446	4 CLIP
519447	2 SPRING
519751	1 RACE REPLACES 604476
519777	2 BEARING WOOD
519814	1 CASE
519833	2 BEARING ASSY
519835	35 BUSHING,BRASS
519966	2 REEL SHAFT ASSY
519979	1 ARM, REEL
519981	38 BRACE, REEL ARM
519991	1 BRACKET, STRAW RACK

520041	1 HUB
520065	1 SHEAVE 16"
520072	5 DOOR GRAINELEVATOR
520082	2 SPROCKET 6T
520106	1 BRACKET STRAW HOOD
520545	2 BAR CONCAVE
520899	2 BLOCK
520939	2 SPRING
521062	4 HUB
521316	1 SLIDE, CHAIN
521513	1 DEFLECTOR LARGE
521982	1 AUGER
522281	2 PLATE
522282	2 RING
522985	2 SICKLE BEARING
523290	6 SLAT ASSY
523362	6 BAT
523627	14 GRAIN TANK DOOR
523629	1 GUIDE, GRAIN DOOR
524000	2 BEARING
524139	3 SHEAVE GEAR BOX
524141	1 CYLINDER SHEAVE
525216	2 HUB
525736	2 PIN YOKE QUICK LOCK PTO
526374	1 SHAFT, GRAIN ELEVATOR
526381	1 DEFLECTOR CYLINDER HOUSING
526434	1 ROCKER ARM
526990	3 BUSHING
527068	5 BUSHING
527321	1 BUSHING, RUBBER
527322	1 BUSHING RUBBER HANGER
527336	1 BUSHING
528518	5 BALL BEARING CYLINDER SEALED
528519	2 BEARING, BALL
528808	2 CYL PLATE ASSY
528811	1 HOUSING
529336	1 GEAR
532782	1 DECAL AC DIAMOND
533147	2 GUIDE, SICKLE
533191	11 DECAL 72
533259	1 PTO SPRING
533260	1 HUB SICKLE LINK
533261	58 BUSHING RUBBER
533265	1 BUSHING
533266	1 PIVOT PIN
533279	1 SPROCKET
533295	1 SPRING

533434	3 GUIDE, SICKLE
533444	1 DIVIDER
533448	1 SICKLE GUIDE
534101	1 CABLE HEADER LIFT
534259	4 RETAINER OUTER
534260	7 RETAINER INNER
534261	12 BLOCK
534282	1 BEARING ASSY
535491	2 PIN
535496	1 HEAD, SICKLE
535502	2 SHEAVE
535503	1 SHEAVE
535507	2 SHEAVE
535513	1 HUB
535516	8 KEY
535526	2 PIN
535537	19 GUIDE, SICKLE
535543	8 BUSHING, RUBBER
535546	86 SHIM GEAR COVER
535547	85 SHIM TUBE
535563	3 HUB, FAN SHEAVE
535564	16 HOLD DOWN, SICKLE
535568	42 LINK ATTACHING
535582	2 PULLEY
535594	9 SPRING
538286	3 SHIM
538288	1 RETAINER
540426	2 SPROCKET
540445	4 LINING SLIP CLUTCH
540498	1 GUARD HEADER GRAIN
540672	1 HEADER PIVOT
543132	12 CHAIN #55
550244	7 CAP, SPRING
580962	1 CORN HEADS OPERATORS PROFILE
802094	11 BOLT
802154	2 ROD
802171	1 BELT
802932	4 PITMAN
803350	2 HUB
805050	2 BALL BEARING (1109048)
902872	2 SETSCREW
905123	4 WOODRUFF KEY
905126	21 KEY WOODRUFF
910192	10 PIN SHEAR
910288	2 RIVET
910298	2 RIVETS
910315	8 KEY

910317	30 KEY
910516	108 RIVET FOR BUCKETS
910544	6 SETSCREW
911176	20 RIVET, COUNTERSINK
911240	17 RIVET, COUNTERSINK
913833	4 PLOW BOLT
913986	13 PLOW BOLT
915701	191 RIVET
915710	3 SCREW
916171	6 PIN
917148	2 BALL, DETENT
920653	21 RIVET COUNTERSUNK 3/16" X 2"
921019	20 PIN, ROLLER
922091	6 WASHER
922093	4 WASHER
933214	9 PIN, ROLLER
1113372	1 ROLLER BEARING
1113373	8 BEARING W/COLLAR
1114839	4 FLANGE
1116256	1 WOOD
9001306	1 PARTS CATALOG
9001318	1 PARTS CATALOG CORN HEAD
70828305	4 MANUAL OPERATORS
70828308	2 MANUAL 90
501967-R	8 AUGER TUBE UNLOADING REPAIR
533143S	5 SICKLE BAR
55CO	2 DETACHABLE ATTCHING LINK
C5D-1511	3 BEARING
C5D-1644	2 HANGER
C5D-1645	2 HANGER STRAW RACK REAR
C5D-1654	1 GRAIN DRAG TENSIONER
C5D-1680	1 BEARING
C5D-1727	3 SPROCKET
D-2	4 DEALERS REPAIR PARTS CATALOG
D-21	1 DEALERS PARTS CATALOG
D-24	3 DEALERS REPAIR PARTS CATALOG 60 A
D-28	8 DEALER REPAIR PARTS CATALOG
D-32	4 DEALER REPAIR PARTS CATALOG
D-36	3 DEALERS REPAIR PARTS CATALOG
D-37	1 DEALERS CATALOG SPECIAL ATTACHMENTS
D-39	3 DEALERS PARTS CATALOG SPECIAL ATTACHMENTS
D-41	2 DEALER PARTS CATALOG
D-42	2 DEALERS PARTS - SECTION II
D-42 (A)	2 DEALER PARTS CATALOG GLEANER A,R,B
D42(III)	2 DEALERS PARTS CATALOG SECTION III
D-43	2 DEALERS PARTS CATALOG SPECIAL ATTACHMENTS
D-52	3 DEALERS PARTS CATALOG SECTION 1

D-52 (A)	2 DEALER PARTS CATALOG GLEANER C,C II
D-53	1 DEALERS PARTS CATALOG SPECIAL ATTACHMENTS
D-64	1 DEALER PARTS CATALOG
D-64 (A)	1 DEALER PARTS CATALOG GLEANER A II
D-82	1 PARTS CATALOG CORN HEADS
D-84	1 PARTS CATALOGS CORN HEADS
D-92	1 PARTS CATALOG CORN HEADS
DEALER60	3 DEALER REPAIR PARTS CATALOG
DSM-14	1 DEALERS INSTRUCTIONS SETTING UP
DSM-9	1 SET UP INSTRUCTIONS
R-501730	2 REPLACEMENT FOR 501730
TM-107A	2 OPERATORS MANUAL
TM-134	1 OPERATING INSTR & PARTS ILLUS
TM-136	1 OPERATORS MANUAL
TM-139	1 OPERATORS MANUAL
TM-152	1 OPERATORS INSTRUCTIONS
TM-162A	1 OPERATORS INSTRUCTIONS MODEL A GLEANER
TM-199	1 OPERATORS INSTRUCTIONS
TM-213	1 OPERATORS INSTRUCTIONS MODEL 50
TM-219A	1 OPERATORS INSTRUCTIONS
TM-234A	1 OPERATORS INSTRUCTIONS
TM-239A	1 OPERATORS INSTRUCTIONS
TM-256	1 OPERATORS INSTRUCTIONS
TM-375B	1 OPERATORS MANUAL
TM-376B	1 OPERATORS MANUAL
TM-467	1 OPR INSTRUCTIONS & SETTING UP INST CORN HEADS
TM-468	1 OPR INSTRUCTIONS & SET UP CORN HEADS
TM-86B	1 OPERATING INSTR & REPAIR PARTS ILLUS
TPL-128A	1 AUX ENGINE PARTS LIST ALL-CROP 60
TPL-128B	1 AUX ENGINE PARTS LIST ALL-CROP 60
TPL-241A	1 REPAIR PARTS LIST
TPL-275	2 REPAIR PARTS LIST
TPL-275A	1 PARTS LIST
TPL-276	1 REPAIR PARTS LIST
TPL-305	1 PARTS LIST
TPL-309	2 PARTS LIST 9FT-12FT GLEANER BALDWIN
TPL-339A	2 PARTS ILLUSTRATION
TPL-339B	1 PARTS ILLUSTRATIONS MODEL 90
TPL-348	1 PARTS ILLUSTRATION
TPL-362	1 TWO ROW CORN HEAD MODEL A
TPL-382	1 PARTS ILLUSTRATIONS MODEL 50
TPL-95B	1 ATTACH INSTR & REPAIR PARTS FOR
TPL-95C	3 ATTACH INSTR & REPAIR PARTS FOR