

## All-Crop Harvester Serial Number List

### **Model 40**

1938 101-200  
1939 201-6200  
1940 6201-15200

### **Model 60**

1935 6848-7397  
1936 7398-15050  
1937 15051-23800<number gap> 23829-26695  
1938 23801-23825 <number gap> 26696-42015  
1939 42016-49831  
1940 49837-58836  
1941 60105-71391  
1942 71392-86336  
1943 86337-91162<number gap>91169-95388  
1944 95389-104449  
1945 104450-120473  
1946 120474-128763  
1947 128764-149588  
1948 149589-168563  
1949 168564-183923

### **Model 60A**

1949 A101-4679  
1950 A4680-32584  
1951 A32585-60244  
1952 A60245-75100

**Model 66**

1953 B101-20379  
1954 B20380-33419  
1955 B33420-51410  
1956 B51411-59718  
1957 B59719-66686  
1958 B66687-70371  
1959 B70372-?

**Model 72**

1959 101-724  
1960 725-2001  
1961 2002-2932  
1962 2933-4632  
1963 4633-5887  
1964 5888-7011  
1965 7012-7511  
1966 7512-?  
1968 9001-?  
1969 9093-?